

Section II

The Structure of Macromolecules: *Human muscarinic M3 and bovine rhodopsin sequences alignment - tutorial*

Liliana Halip, Dan C. Fara and Tudor I. Oprea

Objective

To learn how to use T-Coffee for sequences alignment.

Brief info

A sequence alignment consists in the primary sequences arrangement of proteins, DNA or RNA, in order to identify regions of similarity that may be a result of functional, structural, or evolutionary relationships between those sequences. Aligned sequences are typically represented as rows within a matrix, and identical or similar characters must be aligned in successive columns. Gaps may be inserted between the residues if it is necessary. There are several web-based programs that can be used for sequences alignment. The main ones are [BLAST](#)^{1,2}, [ClustalW](#), and [T-Coffee](#)³.

T-Coffee runs by assembling a library - a list of potential pairs of residues and then turns this library into an alignment. Each library line is a constraint and the purpose is to assemble the alignment that accommodates the more all the constraints.

For this tutorial, the human muscarinic M3 (hM3) and bovine rhodopsin (RHO) sequences were chosen to be aligned using T-Coffee. The bovine rhodopsin is the only protein belonging to the same family with hM3 receptor (G-protein coupled receptors, GPCR) having the 3D structure available from experimental studies (X-RAY or RMN studies).

How to

1. Obtain the proteins sequences

- go to [Swiss-PROT](#)^{4,5} (the protein sequence database).
- enter the protein name (e.g. muscarinic M3 receptor) in the query field - see Figure 1; you will be directed to a new page where you can find the results of your query.

ExPASy - UniProt Knowledgebase: Swiss-Prot and TrEMBL - Windows Internet Explorer

http://expasy.org/sprot/

File Edit View Favorites Tools Help

UniProt Knowledgebase user ... ExPASy - UniProt Knowle...

ExPASy Home page Site Map Search ExPASy Contact us PROSITE Proteomics tools

Notice: This page will be replaced with beta.uniprot.org. Please send us your feedback!

Search for

swissprot **Swiss-Prot**
Protein knowledgebase
TrEMBL
Computer-annotated supplement to Swiss-Prot

UniProt

The UniProt Knowledgebase consists of:

- **UniProtKB/Swiss-Prot**; a curated protein sequence database which strives to provide a high level of annotation (such as the description of the function of a protein, its domains structure, post-translational modifications, variants, etc.), a minimal level of redundancy and high level of integration with other databases [[More details](#) / [References](#) / [Linking to Swiss-Prot](#) / [User manual](#) / [Recent changes](#) / [Disclaimer](#)].
- **UniProtKB/TrEMBL**; a computer-annotated supplement of Swiss-Prot that contains all the translations of EMBL nucleotide sequence entries not yet integrated in Swiss-Prot.

These databases are developed by the Swiss-Prot groups at [SIB](#) and at [EBL](#).

UniProt Knowledgebase Release 12.4 consists of:
 UniProtKB/Swiss-Prot Release 54.4 of 23-Oct-2007: 287050 entries ([More statistics](#))
 UniProtKB/TrEMBL Release 37.4 of 23-Oct-2007: 4988379 entries ([More statistics](#))

> **Swiss-Prot headlines**
 More controlled vocabulary in the 'Subcellular location' subsection (Read [more...](#))

Access to the UniProt Knowledgebase

- **SRS** - Access to UniProtKB/Swiss-Prot, UniProtKB/TrEMBL and other databases using the Sequence Retrieval System
- **Full text search** in the UniProt Knowledgebase
- **Advanced search in the UniProt Knowledgebase** by description, gene name and organism (can be used to create html links to UniProt Knowledgebase queries)
- **Taxonomy browser (NEW!)**
- **BLAST** similarity search
- **by description or identification** (any word in the DE, OS, OG, GN and ID lines)

Figure 1

- select/open the record for the human M3 sequence (SWISS PROT ID: P20309) – see Figure 2. At the end of this page, in the sequence section, you have the option to view the protein sequence as FASTA format – see Figure 3.

Search in UniProt Knowledgebase (Swiss-Prot and TrEMBL) for: muscarinic M3 receptor - Windows Internet Explorer

http://www.expasy.org/cgi-bin/sprot-search-de?muscarinic%20M3%20receptor

File Edit View Favorites Tools Help

UniProt Knowledgebase user ... Search in UniProt Knowle...

ExPASy Home page Site Map Search ExPASy Contact us Swiss-Prot

Hosted by Switzerland Mirrors sites: Australia Brazil Canada China Korea

Notice: This page will be replaced with beta.uniprot.org. Please send us your feedback!

Search

Search in UniProt Knowledgebase (Swiss-Prot and TrEMBL) for: muscarinic M3 receptor

UniProtKB/Swiss-Prot Release 54.4 of 23-Oct-2007
UniProtKB/TrEMBL Release 37.4 of 23-Oct-2007

- Number of sequences found in UniProt Knowledgebase (Swiss-Prot₍₁₀₎ and TrEMBL₍₁₁₎): **21**
- Note that the selected sequences can be saved to a file to be later retrieved; to do so, go to the **bottom** of this page.
- For more directed searches, you can use the Sequence Retrieval System [SRS](#).

Search in UniProtKB/Swiss-Prot: There are matches to 10 out of 287050 entries

[ACM3_BOVIN \(P41984\)](#)
Muscarinic acetylcholine receptor M3. {GENE: Name=CHRM3}-Bos taurus (Bovine)

[ACM3_CAEEL \(Q9U7D5\)](#)
Muscarinic acetylcholine receptor gar-3 (G-protein-linked acetylcholine receptor 3) {GENE: Name=gar-3; ORFNames=Y40H4A.1}-Caenorhabditis elegans

[ACM3_CHICK \(P49578\)](#)
Muscarinic acetylcholine receptor M3. {GENE: Name=CHRM3}-Gallus gallus (Chicken)

[ACM3_GORGO \(Q9N2A3\)](#)
Muscarinic acetylcholine receptor M3. {GENE: Name=CHRM3}-Gorilla gorilla gorilla (lowland gorilla)

[ACM3_HUMAN \(P20309\)](#)
Muscarinic acetylcholine receptor M3. {GENE: Name=CHRM3}-Homo sapiens (Human)

[ACM3_MOUSE \(Q9ERZ3\)](#)
Muscarinic acetylcholine receptor M3 (Mm3 mAChR). {GENE: Name=Chrm3; Synonyms=Chrm-3}-Mus musculus (Mouse)

[ACM3_PANTR \(Q9N2A4\)](#)
Muscarinic acetylcholine receptor M3. {GENE: Name=CHRM3}-Pan troglodytes (Chimpanzee)

[ACM3_PIG \(P11483\)](#)
Muscarinic acetylcholine receptor M3. {GENE: Name=CHRM3}-Sus scrofa (Pig)

[ACM3_PONPY \(Q9N2A2\)](#)
Muscarinic acetylcholine receptor M3. {GENE: Name=CHRM3}-Pongo pygmaeus (Orangutan)

[ACM3_RAT \(P08483\)](#)
Muscarinic acetylcholine receptor M3. {GENE: Name=Chrm3; Synonyms=Chrm-3}-Rattus norvegicus (Rat)

Search in UniProtKB/TrEMBL: There are matches to 11 out of 4988379 entries

Figure 2

UniProtKB/Swiss-Prot entry P20309 [ACM3_HUMAN] Muscarinic acetylcholine receptor M3 - Windows Internet Explorer

http://www.expasy.org/uniprot/P20309#seq

File Edit View Favorites Tools Help

UniProt Knowledgebase user ... UniProtKB/Swiss-Prot ent... X

MUTAGEN 281 281 V->A: Loss of basolateral sorting.
 MUTAGEN 281 281 V->L: No effect on basolateral sorting.
 CONFLICT 382 384 KLP -> RLS (in Ref. 7; AAG30036).
 STRAND 280 283 4

Sequence information

Length: **590 AA** [This is the length of the unprocessed precursor] Molecular weight: **66128 Da** [This is the MW of the unprocessed precursor] CRC64: **5CB473C57B9526E9** [This is a checksum on the sequence]

10	20	30	40	50	60
MTLHNNTTS	PLFPNISSW	IHSPSDAGLF	PGTVTHFGSY	NVSRAGNFS	SPDGTDDPL
70	80	90	100	110	120
GGHTVQVVF	IAFLTGILAL	VTIIGNILVI	VSPKVNKQLK	TVNNYFLSL	ACADLIIGVI
130	140	150	160	170	180
SMNLETTYII	MNRWALGNLA	CDLWLAIDYV	ASNASVMNLL	VISFDYFISI	TRFLTYRAKR
190	200	210	220	230	240
TTKRAGVMIG	LAWVISFVLW	APAILFWQYF	VGKRTVPPGE	CFIQFLSEPT	ITFGTAIAAF
250	260	270	280	290	300
YMPVTIMTIL	YWRIYKETER	RTKELAGLQA	SGTEAETENF	VHPTGSSRSC	SSYELQQQSM
310	320	330	340	350	360
KRSNRKRYGR	CHFVFTTKSW	KPSSEQMDQD	HSSSDSWNNN	DAAASLENSA	SSDEEDIGSE
370	380	390	400	410	420
TRAIYSIVLK	LPGHSTILNS	TKLPSSDNLQ	VPEEELGMVD	LERKADKLQA	QKSVDDGGSF
430	440	450	460	470	480
PKSFKLPIQ	LESVDTAKT	SDVNSSVGKS	TATLPLSFKE	ATLAKRFALK	TRSQITKRRK
490	500	510	520	530	540
MSLVKPKAA	QTLSAILLAF	IITWTPYNIM	VLVNTPCDSC	IPKTFWNLGY	WLCYINSTVN
550	560	570	580	590	
PVCYALCNKT	FRITTFKMLL	CQCDKKKRRK	QQYQQRQSVI	PHKRAPEQAL	

[P20309 in FASTA format](#)

[View entry in original UniProtKB/Swiss-Prot format](#)
[View entry in raw text format \(no links\)](#)

Figure 3


- save the sequence (in FASTA format) as a text file.
- repeat the above-given steps for bovine rhodopsin and save the sequence OPSD_BOVIN (SWISS PROT ID: P02699)
- merge the two text files into a single one and save it as “sequences.txt”

2. Align the proteins sequences

- access the [T-Coffee server](#)

Note that the following five modules are available for proteins sequences alignment: (i) T-Coffee, (ii) Expresso (it replaces 3DCoffee), (iii) M-Coffee, (iv) Rcoffee (beta version), and (v) Combine. *T-Coffee* computes a multiple sequence alignment and the associated phylogenetic tree. *Expresso* computes **structure** based multiple sequence alignments by running a BLAST alignment between every sequence in the query against the PDB database. If it finds one structure similar enough to a sequence in your dataset (>60% identity), it will use it as a template for your sequence. *M-Coffee* computes a multiple sequence alignment and the associated phylogenetic tree by combining the output of several multiple sequence alignment packages (PCMA, Poa, Mafft, Muscle, T-Coffee, ClustalW, ProbCons, DialignT). *Rcoffee* computes multiple sequence alignment of **non coding** RNA sequences using [RNAplfold](#) predicted secondary structures. *Combine* combines two (or more) multiple sequence alignments into a single one. Details about each of these modules can be found by following the link “[cite](#)” to the original papers.

- go to T-Coffee > Advanced and input the sequences in Fasta format. This can be done in two ways: (i) either upload the text file containing both sequences in Fasta format (sequences.txt), or (ii) paste both proteins sequences in Fasta format (no empty line between the sequences). Keep the default options for the “Alignment computation” and the “Output”, as can be seen in Figure 4:



Swiss Institute of Bioinformatics Institut Suisse de Bioinformatique
Schweizerisches Institut für Bioinformatik

TCOFFEE::Advanced

Computes a **multiple sequence alignment** and the associated **phylogenetic tree**.

Limitations: Maximum number of sequences is **50**
Maximum length of sequences is **2000**

Sequence Input

Paste or upload your set of sequences in [fasta](#) format.

[Upload File](#)

or paste data

```
PKSFSKLP IQLES AVDTAKTSDVNSSVGKSTATLPLSFKEATLAKRFALKTRSQITKRKR
MSLVKEKKAQTL SAILLAFIITWTPYNIMVLVNTFCDSICPKTFWNLGYWLCYINSTVN
PVCYALCNKTFRTTFKMLLLQCCKKKRRKQQYQQRQSVIFHKRAPEQAL
>P02699|OPSD BOVIN Rhodopsin - Bos taurus (Bovine).
MNGTEGPNFYVPFSNKTGVVRSFPFEAPQYLLAEPWQFSMLAAYMFLLIMLGFPINFLTY
VTVQHKKLRTPLNYILNLAVADLFMVFGGFTTTLTSLHGYFVFPGTGCNLEGFFATLG
```

Alignment Computation

Tcoffee computes its alignments by combining a collection of smaller alignments named a Library. In this section you can select the methods you want to combine into the Toffee library. You can choose pairwise and multiple sequence alignment methods.

[Pairwise Methods](#)

☒ Mlalign_id_pair ☐ Mclustalw_pair
☐ Mfast_pair
☒ Mslow_pair

Output

Use this section to control the Output Format.

[Alignment Format](#)

☒ clustalw_aln ☐ pir_aln ☐ pir_seq ☒ score_pdf
☐ gcg ☒ fasta_aln ☐ fasta_seq ☐ score_ascii
☐ msf_aln ☒ phylip ☒ score_html

[Case](#)

[Residue Number](#)

[Order](#)

Figure 4

- press the submit button and wait until the sequence alignment will be computed. The results are given in different formats – see Figure 5. The high-similarity regions in the alignment are marked yellow/red in the HTML or PDF format.

Swiss Institute of Bioinformatics

Institut Suisse de Bioinformatique

Schweizerisches Institut für Bioinformatik

[HOME](#) | [references](#) | [help](#) | [✉](#)

TCOFFEE :: Advanced

Your data will remain available on this server over the next 9 days. It will then be deleted.
Do not forget to bookmark this [URL](#) or save it for further reference.

RESULTS					
Multiple Alignment	clustalw aln	score pdf	fasta aln	phylip	score html
System files	LOG	Command line			
Inputs	tcfTCOA24157_863.in0				

SEND RESULTS		
	<input type="button" value="to ProtoGene"/>	PROTOGENE: turning amino acid alignments into bona fide CDS nucleotide alignments
	<input type="button" value="to MSA hub"/>	MyHits: a new interactive resource for protein annotation and domain identification

Home Server: [TCOFFEE :: Advanced](#)

Figure 5

The sequence alignment is the most critical step in developing a homology model, for example a misalignment by just one residue will cause an error around 4Å in the model. For an accurate alignment the **structurally-conserved regions** (SCRs) have to be identified in both sequences. Structurally-conserved regions within a family proteins refer to the fragments for which an average structure or framework can be constructed for these regions of the proteins.

In rhodopsin-like family the highly conserved amino acids are⁶:

- Gly17, Asn 18 and Val21 on helix I,
- Asn or Ser9, Leu10, Ala11, Ala or Ser13, and Asp14 on helix II,
- Ser 14, Leu 18, Ile 21, Ser or Ala22, Asp or Glu24, Arg 25, Tyr 26, Ile or Val29, on helix III,
- Trp11, Ser or Ala14 and Pro20 on helix IV,
- Phe11, Pro14, Ile or Met18, Tyr22 and Ile or Val25 on helix V,
- Lys or Arg0, Phe12, Cys15, Trp16 and Pro18 on helix VI,
- Asn or Ser13, Ser or Cys14, Asn or Asp17, Pro18, Tyr21, Phe or Tyr28 and Arg or Lys29 on helix VII.

After highly conserved residues identification in the alignment (yellow background in figure 6) one can observe that T-coffee fails to find the common motif in the helices 5 (green background in figure 6). This is due to the fact that the third intracellular loops have obviously different lengths (218 residues in M3 receptor versus 25 residues in rhodopsin). To avoid this inconvenient, a new alignment is necessary, this time using a short sequence for hM3 receptor (the short sequence does not contain all the amino acid residues from the third loop). This deletion will not have a bad influence on following studies (e.g. docking) because the binding site is

located in the transmembranar region. In Figure 6 bold letters indicate the transmembranar domains; the fifth transmembrane is pointed out with bold and italic letters.

CLUSTAL FORMAT for T-COFFEE Version_5.13 [http://www.tcoffee.org], CPU=0.09 sec, SCORE=63, Nseq=2, Len=595

```
P02699|OPSD_BOVIN  ----MNGTEGPNF-----YVPFSNKTGV-----VRSPFEAPQYYLAEP- 34
P20309|ACM3_HUMAN  MTLHNNSTTSPLFPNIISSSWIHSPSDAGLPPGTVTHFGSYNVSRAGNFSSPDGTTDDPL 60
                *. * . * *      ::  . . . : :      . . * . : :      : *

                TM I                      TM II
P02699|OPSD_BOVIN  ----WQFSMLAAYMFLIMLGFPINFLTLVTVQHKKLRTPLNYILLNLAVADLFMVFG 89
P20309|ACM3_HUMAN  GGHTVWQVVFIAFLTGILALVTIIGNILVIVSFKVKNQKLTVNNYFLLSLACADL--IIG 118
                ** . : : *      : * : :      : * : :      : * : :      : * : :      : * : :      : * : :      : * : :

                TM III
P02699|OPSD_BOVIN  GFTTTLYTS--LHGYFVFGPTGCNLEGFFATLGGEIALWSLVVLAIERYVVCKPMS-NF 146
P20309|ACM3_HUMAN  VISMNLFTTYIIMNRWALGNLACDLWLALIDYVASNASVMNLLVISFDRYFSITRPLTYRA 178
                : : . * : :      : . : : *      : . : :      : . : :      : . : :      : . : :      : . : :      : . : :

                TM IV
P02699|OPSD_BOVIN  RFGENHAIMGVAFTVMALACAAPPLVGWSRYI----- 179
P20309|ACM3_HUMAN  KRTTKRAGVMIGLAWVISFVLWAPAILFWQYFVGKRTVPPGECFIQFLSEPTITFGTAIA 238
                :      : : * : : : : : * : : * . : :      : : :

P02699|OPSD_BOVIN  -----PEGMQCSCGI----- 189
P20309|ACM3_HUMAN  AFYMEVTITILYWRYKETEKRTEKELAGLQASGTEAETENFVHPTGSSRSCSSYELQQQ 298
                * * . * * .

P02699|OPSD_BOVIN  -----DYYTPHEETN 199
P20309|ACM3_HUMAN  SMKRSNNRKYGRCHFWFTTKSWKPSSEQMDQDHSSSDSWNNNDAAASLENSASSDEEDIG 358
                .      : . * : .

P02699|OPSD_BOVIN  NESFVIYMFVVHF----- 212
P20309|ACM3_HUMAN  SETRAIYSIVLKLPGHSTILNSTKLPSSDNLQVPEEELGMVDLERKADKLQAQKSVDDGG 418
                . * : . * * : : : :

P02699|OPSD_BOVIN  -----IIILIV-----IFFCYQQLVFTVKEAA-----AQQQE 239
P20309|ACM3_HUMAN  SFPKSFSLKPIQLESAVDTAKTSDVNSSVGKSTATLPLSFKEATLAKRFALKTRSQITKR 478
                : * : :      :      : . . * : : . * : :      : .

                TM VI
P02699|OPSD_BOVIN  SATTQKAEKVTRMVIIMVIAFLICWLPYAGVAFYIFTHQGSDFGPIFMTIPAFFAKTSA 299
P20309|ACM3_HUMAN  KRMSLVKEKAAQTLSAILLAFIIITWTPY-NIMVLVNTFCDISCPKTFWNLGYWLCYINS 537
                .      :      * : : : : : * : * * . : . : * . * :      * : : : . . :

                TM VII
P02699|OPSD_BOVIN  VYNFVIYIMNKQFRNCMVTTLC-----GKNPLGDDEASTTVSKTETSQVAPA 348
P20309|ACM3_HUMAN  TVNFCYALCNKTFRTTFKMLLLCQCDKKRRKQQYQQRSVIFHKRAPEQA--L 590
                . * * * * : * * * . :      * *      : :      : . * . * . * .
```

Figure 6

Therefore the improved alignment must be accomplished so that the SCRs from the two sequences are perfectly aligned. In the same time, each transmembrane alignment must not contain insertion or deletion at their level. If that happens, they have to be moved in loop regions for the sake of the accuracy of the alignment. As one can see from Figure 6 such operations have to be performed at helix 2 and 6 levels. In order to avoid the induction of perturbations it is better to eliminate the insertions before helix 1 and after helix 8. Also helices 5 must be manually realigned. Based on these modifications and by removing a part of CIII loop a new alignment is obtained – see Figure 7.

CLUSTAL FORMAT for T-COFFEE Version_5.13 [http://www.tcoffee.org], CPU=0.07 sec, SCORE=64, Nseq=2, Len=390

```
                TM I
P02699|OPSD_BOVIN  MNGTEGPNFYVPFSNKTGVVRSPFEAPQYYLAEPWQFSMLAAYMFLIMLGFPINFLTLVTV
P20309|ACM3_HUMAN  NNSTTSPLFWIHSPSDAGLAAGNFSSPDGTTDDPWQVVFIAFLTGILALVTIIGNILVIVSFK
```

TM II TM III

P02699|OPSD_BOVIN QHKKLRTPNLYILLNLAVADLFMVFGGFTTTLYTSLHGYFVFGPTGCNLEGFFATLGGEIALWS
P20309|ACM3_HUMAN VNKQLKTVNNYFLLSLACADLIIGVISMNLFTTYIIMNRWALGNLACDLWLAIDYVASNASVMN

TM IV

P02699|OPSD_BOVIN LVVLAIERYVVVCKPMS-NFRFGENHAIMGVAFWVMALACAAPPLVGWSRYIPEGMQCSCGID
P20309|ACM3_HUMAN LLVISFDRYFSITRPLTYRAKRTTKRAGVMIGLAWVISFVLWAPAILFWQYFVGKRTVPPG---

TM V

P02699|OPSD_BOVIN YYTPHEETNNESFVIYMFVVHFIILIVLFFCYGQLVF-TVKEAAQQQESATTQKAEKEVTRM
P20309|ACM3_HUMAN -ECFIQFLSEPTITTFGTAIAAFYMFVTITILYWRKYKETEKRTKLQQQ-KRMSLVKEKKAAQT

TM VI TM VII

P02699|OPSD_BOVIN VIIMVIAFLICWLPYAGVAFYIFTHQGSDFGPIFMTIPAFFAKTSAVYNPVIYIMMNKQFRNCM
P20309|ACM3_HUMAN LSAILLAFIITWTFYNIMVLVNTFCDSIP-KTFWNLGWLCYINSTVNEVCYALCNKTFRTTF

P02699|OPSD_BOVIN VTTLCCKGNPLGDDEASTTVSKTETSQV
P20309|ACM3_HUMAN KMLLLCRRKQQYQQRQSVIFHKRAPEQA

Figure 7

- compare your newly obtained short sequence of amino acids for hM3 receptor with this one [insert link]
- correct the errors
- save the corrected sequence as text file, i.e. h3M_short_seq.txt (!keep the first line from the initial text file!), because you will need it in the next section of the course.

¹ Altschul S.F., Madden T.L., Schaffer A.A., Zhang J., Zhang Z., Miller W., Lipman D.J., *Nucleic Acids Res* 25 (1997) 3389-3402

² Jaroszewski L., Rychlewski L., Zhang B., Godzik A., *Protein Sci* 7 (1998) 1431-1440

³ C. Notredame, D. Higgins, J. Heringa *Journal of Molecular Biology*, 302, 205-217, (2000)

⁴ Bairoch A., Apweiler R., *Nucleic Acids Res.*, 28 (2000) 45-48

⁵ <http://www.expasy.org/sprot/sprot-top.html>

⁶ Baldwin, J.M.; Schertler, G.F.X.; Unger, V.M. *J Mol Biol* 1997, 272, 144–164